

SYSTEM INITIALIZATION

After assembly of desk is complete, it is necessary to reset or initialize the motor system.



STEP 1:

Plug the power cord into an outlet or power strip. *(Display will flash)*

STEP 2:

Press and **continue holding** both the **up** (^) and **down** (v) buttons simultaneously until the desk is at its lowest point, the display will flash "000" followed by a beep and the display will then show the lowest height. *(The buttons can now be released)*

NOTE:

If initialization is interrupted by releasing buttons prematurely *(display will read "000")* and/or if desk does not begin moving, repeat step 2.

STEP 3:

Press the **up** (^) button to raise the desk to the highest position. *(Now release the button)*

STEP 4:

Press the **down** (v) button to lower the desk to the lowest position. *(Now release the button)*

(The system has now been successfully initialized and synced)

INSTALACION DE CONTROL DE MESA Y SINCRONIZACION

DESPUES DE COMPLETAR EL ENSAMBLAJE ES NECESARIO REINICIAR O INICIALIZAR EL SISTEMA DEL MOTOR, POFAVOR DE SEGUIR LOS SIGUIENTES PASOS:

PASO 1:

Conecte el cable de corriente en el enchufe. *(la pantalla va a prender)*

PASO 2:

Presione los botones de (^) arriba y (v) abajo al mismo tiempo hasta que las patas de las columna esten en su punto mas bajo y continúe presionando los botones hasta que la pantalla ensene "000". Luego sonara un pitido y la pantalla mostrara el numero de la medida mas baja, despues de haber echo esto suelta los botones.

NOTA:

Si la inicializacion se interrumpe al soltar los botones prematuramente la pantalla mostrara "000" o si no se mueve, repita el paso dos.

PASO 3:

Presione el boton de arriba (^) para elevar la mesa ala posicion mas alta, despues he haber echo esto suelta el boton.

PASO 4:

Presione el boton de abajo (v) para elevar la mesa ala posicion mas baja, despues he haber echo esto suelta el boton.

(El sistema se ha inicializado y sincronizado con exito)

HEIGHT ADJUSTABLE BASE **OPERATION GUIDE**



METRIC OR IMPERIAL HEIGHT SETTING:

The controller can show either Metric (cm) or Imperial (in) height.

STEP 1:

Press the **(1)** **(2)** **(M)** buttons simultaneously for 5 seconds until "C-E" appears on the display.
Now Release the buttons.

STEP 2:

While the display is flashing, press the **(1)** button to show Metric height or press the **(2)** button for the Imperial mode. *(If (1) or (2) is NOT pressed after the display stops flashing, repeat from Step 1)*

(The height setting is now complete.)

SETTING THE MEMORY FUNCTION:

STEP 1:

Use the up (^) and down (v) buttons to reach the desired height of the desk.

STEP 2:

Press and hold the **(M)** button until the display flashes, then press **(1)**
(Display will read "P1" and position 1 is now memorized.)

Follow the same procedure for memory preset 2, 3, and 4.

(Display will read "P2", "P3" and "P4" when the 2nd, 3rd and 4th positions have been memorized)

(Memorized positions will remain even if power is lost.)

NORMAL OPERATION:

Raise or lower the desk by pressing and holding the up (^) or down (v) button on the Controller until the desired height is reached.

USB Function: Connect desired USB compatible device to USB port to charge.

NOTES:

*Keep base away from water and corrosion-resistant gas.

*Use this base with actual technical parameters.

*Please contact Office Furniture Distributors with any problems or issues at:
cs@ofdist.com or 972-386-5200/Toll Free: 866-648-3635