



BENCH IT EXPANDABLE TROUGHS


1. EXPAND TROUGHS TO DESIRED LENGTH BASED ON LENGTH OF WORKSURFACES USED.




120 DEG TOPS




48" WIDE TOPS



60" WIDE TOPS



66" WIDE TOPS



72" WIDE TOPS


OFD-BI4872WST-XX

The trough can be expanded to work with 48" to 72" wide Work Surfaces - troughs attach to OFD Bench it Legs and must be secured to the bottom of the work-surface where shown for support

(Usar tornillo M5*20 para conectar la superficie)

Please Use M5*20 Screw to Connect the Worksurface.

Adhesive strips that have been included should be installed here (Instalar tiras adhesivas aqui)



Attach the knobs with spacer through the overlapping sections where possible on each side after the length of the trough has been positioned (Fije las perillas con espaciador a traves de las secciones super puestas donde sea posible en cada lado)

Hardware to attach trough to benching legs is in the carton

of legs. (Los accesorios para sujetar el canal alas patas se encuentran en a caja de las patas)