



**FLIP TOP TRAINING TABLE BASE
ASSEMBLY INSTRUCTIONS**







FLIP TOP TRAINING TABLE BASE ASSEMBLY INSTRUCTIONS

EXPLODED VIEW







HARDWARE LIST

			
Ax 8+2 (M6x8)	Bx 4+2 (ST4.8x20)	C X1 (4mm)	D X1 (5mm)

STEP 1 - Attach Modesty Panel


- Attach modesty panel (Item 3).
- Once modesty panel is in place, tighten all screws.





FLIP TOP TRAINING TABLE BASE ASSEMBLY INSTRUCTIONS

STEP 2 - Attach Center Support Beam


- Insert center support beam (Item 5) into center slots on leg and affix with screws (Item A).
- Do not tighten these screws until after Step 3.





	
A x4	C x1

STEP 3 - Attach Outer Support Beams


- Insert outer support beams (Items 4) into outer slots on leg and affix with screws (Item A).
- Tighten all screws securely.





	
A x4	C x1

FLIP TOP TRAINING TABLE BASE ASSEMBLY INSTRUCTIONS


STEP 4 - Attach Table Base to Top



STEP 5 - Operating the Table



Pull to unlock



Down position locked
Up position unlock